USER'S GUIDE

MAYTAG®

SAFETY ..... Pages 1-3

SURFACE COOKING ..... Pages 4-6

OVEN COOKING ..... Pages 7-9

CARE & CLEANING ..... Pages 10-12

BEFORE YOU CALL ..... Page 13

WARRANTY ..... Page 15

GUIDE DE L'UTILISATEUR ..... Page 16

GUÍA DEL USUARIO ..... Page 32

Installer: Please leave this manual with this appliance.

Consumer: Please read and keep this manual for future reference. Keep sales receipt and/or cancelled check as proof of purchase.

Model Number

_ _ _ _ _ _ _ _

Serial Number

_ _ _ _ _ _ _ _

Date of Purchase

In our continuing effort to improve the quality and performance of our cooking products, it may be necessary to make changes to the appliance without revising this guide.

If you have questions, call:
1-800-688-9900 U.S.A.
1-800-688-2002 Canada
1-800-688-2080 (U.S. TTY for hearing or speech impaired)
(Mon.-Fri., 8 am-8 pm Eastern Time)
Internet: http://www.maytag.com

For service information, see page 15.

Form No. A/02/01 Part No. 8113P296-60 MAYTAG ONLINE http://www.maytag.com 74005986 Litho U.S.A.

IMPORTANT SAFETY INSTRUCTIONS

Read and follow all instructions before using this appliance to prevent the potential risk of fire, electric shock, personal injury or damage to the appliance as a result of improper usage of the appliance. Use appliance only for its intended purpose as described in this guide.

WARNING:

IF THE INFORMATION IN THIS MANUAL IS NOT FOLLOWED EXACTLY, A FIRE OR EXPLOSION MAY RESULT CAUSING PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

- **DO NOT STORE OR USE GASOLINE OR OTHER FLAMMABLE VAPORS AND LIQUIDS IN THE VICINITY OF THIS OR ANY APPLIANCE.**
- **IF YOU SMELL GAS:**
  - **Do not try to light any appliance.**
  - **Do not touch any electrical switch.**
  - **Do not use any phone in your building.**
  - **Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.**
  - **If you cannot reach your gas supplier, call the fire department.**
- **INSTALLATION AND SERVICE MUST BE PERFORMED BY A QUALIFIED INSTALLER, SERVICE AGENCY OR THE GAS SUPPLIER.**

WARNING:

- **ALL RANGES CAN TIP AND CAUSE INJURIES TO PERSONS**

- **INSTALL ANTI-TIP DEVICE PACKED WITH RANGE**

- **FOLLOW ALL INSTALLATION INSTRUCTIONS**

WARNING: TO REDUCE RISK OF TIPPING OF THE APPLIANCE FROM ABNORMAL USAGE OR BY EXCESSIVE LOADING OF THE OVEN DOOR, THE APPLIANCE MUST BE SECURED BY A PROPERLY INSTALLED ANTI-TIP DEVICE.

To check if device is properly installed, remove storage drawer and look underneath range to make sure one of the rear leveling legs is properly engaged in the bracket slot. The anti-tip device secures the rear leveling leg to the floor when properly engaged. You should check this anytime the range has been moved.

GENERAL INSTRUCTIONS

To ensure proper and safe operation: Appliance must be properly installed and grounded by a qualified technician. Do not attempt to adjust, repair, service, or replace any part of your appliance unless it is specifically recommended in this guide. All other servicing should be referred to a qualified servicer. Have the installer show you the location of the gas shut off valve and how to shut it off in an emergency.

Always disconnect power to appliance before servicing.

TO PREVENT FIRE OR SMOKE DAMAGE

Be sure all packing materials are removed from the appliance before operating it.

Keep area around appliance clear and free from combustible materials, gasoline, and other flammable vapors and materials.

If appliance is installed near a window, proper precautions should be taken to prevent curtains from blowing over burners.

NEVER leave any items on the cooktop. The hot air from the vent may ignite flammable items and may increase pressure in closed containers which may cause them to burst.

Many aerosol-type spray cans are EXPLOSIVE when exposed to heat and may be highly flammable. Avoid their use or storage near an appliance.

Many plastics are vulnerable to heat. Keep plastics away from parts of the appliance that may become warm or hot. Do not leave plastic items on the cooktop as they may melt or soften if left too close to the vent or a lighted surface burner.

To eliminate the hazard of reaching over hot surface burners, cabinet storage should not be provided

directly above a unit. If storage is provided, it should be limited to items which are used infrequently and which are safely stored in an area subjected to heat from an appliance. Temperatures may be unsafe for some items, such as volatile liquids, cleaners or aerosol sprays.

IN CASE OF FIRE

Turn off appliance and ventilating hood to avoid spreading the flame. Extinguish flame then turn on hood to remove smoke and odor.

- **Cooktop:** Smother fire or flame in a pan with a lid or cookie sheet.

  NEVER pick up or move a flaming pan.

- **Oven:** Smother fire or flame by closing the oven door.

Do not use water on grease fires. Use baking soda, a dry chemical or foam-type extinguisher to smother fire or flame.

CHILD SAFETY

NEVER leave children alone or unsupervised near the appliance when it is in use or is still hot.

NEVER allow children to sit or stand on any part of the appliance as they could be injured or burned.

Children must be taught that the appliance and utensils in it can be hot. Let hot utensils cool in a safe place, out of reach of small children. Children should be taught that an appliance is not a toy. Children should not be allowed to play with controls or other parts of the unit.

CAUTION: NEVER store items of interest to children in cabinets above an appliance or on backguard of a range. Children climbing on the appliance door to reach items could be seriously injured.

ABOUT YOUR APPLIANCE

NEVER use appliance as a space heater to heat or warm a room to prevent potential hazard to the user and damage to the appliance. Also, do not use the cooktop or oven as a storage area for food or cooking utensils.

Do not obstruct the flow of combustion and ventilation air by blocking the oven vent or air intakes. Restriction of air flow to the burner prevents proper performance and increases carbon monoxide emission to unsafe levels.

Avoid touching oven vent area while oven is on and for several minutes after oven is turned off. Some parts of the vent and surrounding area become hot enough to cause burns. After oven is turned off, do not touch the oven vent or surrounding areas until they have had sufficient time to cool.

Other potentially hot surfaces include cooktop, areas facing the cooktop, oven vent, surfaces near the vent opening, oven door, areas around the oven door and oven window.

WARNING: NEVER use appliance door, or drawer, if equipped, as a step stool or seat as this may result in possible tipping of the appliance, damage to the appliance, and serious injuries.

Do not touch a hot oven light bulb with a damp cloth as the bulb could break. Should the bulb break, disconnect power to the appliance before removing bulb to avoid electrical shock.

COOKING SAFETY

Always place a pan on a surface burner before turning it on. Be sure you know which knob controls which surface burner. Make sure the correct burner is turned on and that the burner has ignited. When cooking is completed, turn burner off before removing pan to prevent exposure to burner flame.

Always adjust surface burner flame so that it does not extend beyond the bottom edge of the pan. An excessive flame is hazardous, wastes energy and may damage the appliance, pan or cabinets above the appliance.

NEVER leave a surface cooking operation unattended especially when using a high heat setting or when deep fat frying. Boilovers cause smoking and greasy spillovers may ignite. Clean up greasy spills as soon as possible. Do not use high heat for extended cooking operations.

NEVER heat an unopened container on the surface burner or in the oven. Pressure build-up may cause container to burst resulting in serious personal injury or damage to the appliance.

Use dry, sturdy potholders. Damp potholders may cause burns from steam. Dishtowels or other substitutes should never be used as potholders because they can trail across hot surface burners and ignite or get caught on appliance parts.

Always let quantities of hot fat used for deep fat frying cool before attempting to move or handle.

Do not let cooking grease or other flammable materials accumulate in or near the appliance, hood or vent fan. Clean hood frequently to prevent grease from accumulating on hood or filter. When flaming foods under the hood turn the fan on.

NEVER wear garments made of flammable material or loose fitting or long-sleeved apparel while cooking. Clothing may ignite or catch utensil handles.

Always place oven racks in the desired positions while oven is cool. Slide oven rack out to add or remove food, using dry, sturdy potholders. Always avoid reaching into the oven to add or remove food. If a rack must be moved while hot, use a dry potholder. Always turn the oven off at the end of cooking.

IMPORTANT SAFETY INSTRUCTIONS, CONT.

Use care when opening the oven door. Let hot air or steam escape before moving or replacing food.

PREPARED FOOD WARNING: Follow food manufacturer's instructions. If a plastic frozen food container and/or its cover distorts, warps, or is otherwise damaged during cooking, immediately discard the food and its container. The food could be contaminated.

NEVER use aluminum foil to cover oven racks or oven bottom. This could result in risk of electric shock, fire, or damage to the appliance. Use foil only as directed in this guide.

UTENSIL SAFETY

Use pans with flat bottoms and handles that are easily grasped and stay cool. Avoid using unstable, warped, easily tipped or loose-handled pans. Also avoid using pans, especially small pans, with heavy handles as they could be unstable and easily tip. Pans that are heavy to move when filled with food may also be hazardous.

Be sure utensil is large enough to properly contain food and avoid boilovers. Pan size is particularly important in deep fat frying. Be sure pan will accommodate the volume of food that is to be added as well as the bubble action of fat.

To minimize burns, ignition of flammable materials and spillage due to unintentional contact with the utensil, do not extend handles over adjacent surface burners. Always turn pan handles toward the side or back of the appliance, not out into the room where they are easily hit or reached by small children.

Never let a pan boil dry as this could damage the utensil and the appliance.

Follow the manufacturer's directions when using oven cooking bags.

Only certain types of glass, glass/ceramic, ceramic or glazed utensils are suitable for cooktop or oven usage without breaking due to the sudden change in temperature. Follow manufacturer's instructions when using glass.

This appliance has been tested for safe performance using conventional cookware. Do not use any devices or accessories that are not specifically recommended in this guide. Do not use eyelid covers for the surface units, stovetop grills, or add-on oven convection systems. The use of devices or accessories that are not expressly recommended in this manual can create serious safety hazards, result in performance problems, and reduce the life of the components of the appliance.

CLEANING SAFETY

Turn off all controls and wait for appliance parts to cool before touching or cleaning them. Do not touch the burner grates or surrounding areas until they have had sufficient time to cool.

Clean appliance with caution. Use care to avoid steam burns if a wet sponge or cloth is used to wipe spills on a hot surface. Some cleaners can produce noxious fumes if applied to a hot surface.

IMPORTANT SAFETY NOTICE AND WARNING

The California Safe Drinking Water and Toxic Enforcement Act of 1986 (Proposition 65) requires the Governor of California to publish a list of substances known to the State of California to cause cancer or reproductive harm, and requires businesses to warn customers of potential exposures to such substances.

Users of this appliance are hereby warned that the burning of gas can result in low-level exposure to some of the listed substances, including benzene, formaldehyde and soot, due primarily to the incomplete combustion of natural gas or liquid petroleum (LP) fuels. Properly adjusted burners will minimize incomplete combustion. Exposure to these substances can also be minimized by properly venting the burners to the outdoors.

IMPORTANT NOTICE REGARDING PET BIRDS: Never keep pet birds in the kitchen or in rooms where the fumes from the kitchen could reach. Birds have a very sensitive respiratory system. Fumes released during an oven self-cleaning cycle may be harmful or fatal to birds. Fumes released due to overheated cooking oil, fat, margarine and overheated nonstick cookware may be equally harmful.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

SURFACE COOKING

CLOCK AND TIMER CONTROL



NOTE: The display will flash when electrical power is first supplied to the appliance or if there has been a power failure.

TO SET THE CLOCK:

1. Press the **Clock** pad.
   - ➢ A beep will sound when the **Clock** pad is pressed.
2. Press or press and hold the **More +** or **Less -** pad until the correct time of day appears in the display.
   - ➢ Press to change the time in one minute increments.
   - ➢ Press and hold to change the time in 10 minute increments.

To recall the time of day when the timer is displayed, press the **Clock** pad.

TO SET THE TIMER:

The timer can be set from one minute (0:01) up to 12 hours (12:00). **The timer does NOT control the oven.**

1. Press the **Timer** pad.
   - ➢ A beep will sound when the **Timer** pad is pressed.
   - ➢ 0:00 will appear in the display.
2. Press or press and hold the **More +** or **Less -** pad until the correct time appears in the display.
   - ➢ Press to change the time in one-minute increments.
   - ➢ Press and hold to change the time in 10 minute increments.
   - ➢ Timer will start automatically after a few seconds. The flashing colon indicates that the timer is in use.
   - ➢ If the **Clock** pad is pressed, the colon will continue to flash to indicate the timer is in use.
3. A beep will sound at one minute (0:01).
4. At the end of the timer operation, 0:00 will appear in the display and three beeps will sound.
   - ➢ One beep will sound every 10 seconds for 10 minutes or until the timer operation is cancelled.

TO CANCEL THE TIMER:

Press the **Timer** pad and the current time of day will reappear in the display.

NOTE: When 0:00 is displayed, pressing either the **Timer** or **Clock** pad will also cancel the timer operation.

SURFACE COOKING, CONT.

CAUTION:

- If flame should go out during a cooking operation, turn the burner off. If a strong gas odor is detected, open a window and wait five minutes before relighting the burner.
- Be sure all surface controls are set in the OFF position prior to supplying gas to the range.
- Never touch cooktop until it has cooled. Expect some parts of the cooktop, especially around the burners, to become warm or hot during cooking. Use potholders to protect your hands.

SURFACE CONTROLS

PILOTLESS IGNITION

Pilotless ignition eliminates the need for a constant standing pilot light. Each sealed burner has a spark ignitor. When cleaning around the surface burner use care. If cleaning cloth should catch the ignitor, it could be damaged preventing ignition.

If the surface burner does not light, check if ignitor is broken, soiled or wet. If clogged, clean the small port beneath the ignitor using a straight pin or soft bristle brush.



SURFACE CONTROL KNOBS

Use to turn on the surface burners. An infinite choice of heat settings is available from **LOW** to **HIGH**. At the **HIGH** setting a detent or notch may be felt. The knobs can be set on or between any of the settings.

Graphics near the knob identify which burner the knob controls. For example, this graphic shows the right rear burner location.

SUGGESTED HEAT SETTINGS

The size and type of cookware will affect the flame setting. For information on cookware and other factors affecting flame settings, refer to **"Cooking Made Simple"**.

Setting	Uses

HIGH



Use to bring liquid to a boil, or reach pressure in a pressure cooker. Always reduce setting to a lower heat when liquids begin to boil or foods begin to cook.

An intermediate flame size is used to continue cooking. Food will not cook any faster when a higher flame setting is used than needed to maintain a gentle boil. Water boils at the same temperature whether boiling gently or vigorously.

LOW



Use to simmer foods, keep foods warm and melt chocolate or butter.

SETTING THE CONTROLS

1. Place a pan on the burner grate.
   - ➢ The burner flame may lift off or appear separated from the port if a pan is not placed on the grate.
2. Push in and turn the knob counterclockwise to the **LIGHT** setting.
   - ➢ A clicking (spark) sound will be heard and the burner will light. (All ignitors will spark when any surface burner knob is turned to the **LIGHT** position.)
3. After the burner lights, turn the knob to the desired flame size.
   - ➢ The ignitor will continue to spark until the knob is turned past the **LIGHT** position.

OPERATING DURING A POWER FAILURE

1. Hold a lighted match to the desired surface burner head.
2. Push in and turn the control knob slowly to **LIGHT**.
3. Adjust the flame to the desired level.

CAUTION:

- ➢ When lighting the surface burners, be sure all of the controls are in the OFF position. Strike the match first and hold it in position before turning the knob to LIGHT.

COOKTOP

TO PREVENT THE COOKTOP FROM DISCOLORING OR STAINING:

- ➢ Clean cooktop after each use.
- ➢ Wipe acidic or sugary spills as soon as the cooktop has cooled as these spills may discolor the porcelain.



Unlike a range with standard gas burners, this cooktop does not lift-up nor is it removable. ***Do not attempt to lift the cooktop for any reason.***

SEALED BURNERS

The sealed burners of your range are secured to the cooktop and are not designed to be removed. Since the burners are sealed into the cooktop, boilovers or spills will not seep underneath the cooktop. However, the burners should be cleaned after each use. (See page 11 for cleaning directions.)

HIGH PERFORMANCE BURNER (12,000 BTU*)

(Select Models)

POWER BOOST

This burner offers higher speed cooking that can be used to quickly bring water to a boil and for large-quantity cooking.

** BTU ratings will vary when using LP gas.*

BURNER GRATES

The grates must be properly positioned before cooking. Improper installation of the grates may result in chipping of the cooktop.



Do not operate the burners without a pan on the grate. The grate's porcelain finish may chip without a pan to absorb the heat from the burner flame.

Although the burner grates are durable, they will gradually lose their shine and/or discolor, due to the high temperatures of the gas flame.

NOTES:

- ➢ A properly adjusted burner with clean ports will light within a few seconds. If using natural gas the flame will be blue with a deeper blue inner cone.

  If the burner flame is yellow or is noisy the air/gas mixture may be incorrect. Contact a service technician to adjust. (Adjustments are not covered by the warranty.)

  With LP gas, some yellow tips on the flames are acceptable. This is normal and adjustment is not necessary.
- ➢ If the control knob is turned very quickly from HIGH to LOW, the flame may go out, particularly if the burner is cold. If this occurs, turn the knob to the Off position, wait several seconds and relight the burner.
- ➢ With some types of gas, you may hear a "popping" sound when the surface burner is turned off. This is a normal operating sound of the burner.
- ➢ The flame should be adjusted so it does not extend beyond the edge of the pan.



OVEN COOKING

BAKING AND ROASTING

NOTES:

- You may find that the cooking times and temperatures vary slightly from your old oven. This is normal. Every oven has its own characteristics.
- During some extended oven cooking operations, you may hear a "popping" sound when the oven burner cycles. This is normal.
- See roasting chart in "**Cooking Made Simple**" booklet for recommended roasting temperatures and times and baking and roasting tips.

PILOTLESS IGNITION

Your range is equipped with pilotless ignition. With this type of ignition system, the gas automatically shuts off and ***the oven will not operate during a power failure.***

A lighted match will not light the oven burner. No attempt should be made to operate the oven during a power failure.

SETTING THE KNOB CONTROL FOR BAKING AND ROASTING



The **OVEN TEMP** knob located on the front of the range is used to select and maintain the oven temperature. Always turn this knob just TO the desired temperature. Do not turn to a higher temperature and then back.

1. When cool, position rack in oven.
2. Push in and turn **OVEN TEMP** knob to desired temperature. Allow 10-15 minutes for preheating.
3. Place food in center of oven.
4. Check food for doneness at minimum time in recipe. Cook longer if necessary.
5. Remove food from the oven and turn the **OVEN TEMP** knob to **OFF**.

OVEN BOTTOM

Protect oven bottom against spillovers, especially acidic or sugary spills, as they may discolor the porcelain enamel. Use the correct pan size to avoid spillovers and boilovers. Never place utensils or foil directly on the oven bottom.

The oven bottom may be removed for easier cleaning.



TO REMOVE: When cool, remove the oven racks. Slide the two catches, located at each rear corner of the oven bottom, toward the front of the oven.

Lift the rear edge of the oven bottom slightly, then slide it back until the front edge of the oven bottom clears the oven front frame. Remove oven bottom from oven.

TO REPLACE: Fit the front edge of the oven bottom into the oven front frame. Lower the rear of the oven bottom and slide the two catches back to lock the oven bottom in place.

OVEN VENT

When the oven is in use, never block the vent opening.

The oven vent is located at the base of the backguard. When the oven is in use, this area may become hot enough to cause burns. Do not place plastics near the vent opening as heat from the vent could distort or melt the plastic.

OVEN LIGHT

Push the switch on the control panel to turn the oven light on and off.

OVEN LIGHT

BROILING

SETTING THE KNOB CONTROL FOR BROILING

(Lower Compartment)



1. Place the broiler pan in the recommended broiling compartment position shown in the chart.
2. Turn **OVEN TEMP** knob to **BROIL** or, for lower temperature broiling, to 450°F.
   - ➢ Lower temperature broiling avoids excessive browning of longer cooking foods such as poultry.
3. Follow the suggested times in the broiling chart. Meat should be turned once about halfway through its cooking time.
4. Check the doneness by cutting a slit in the meat near the center to check the color.
5. After broiling, turn the **OVEN TEMP** knob to **OFF**. Remove the broiler pan from the broiler compartment.

For best results, use a broiling pan. For additional broiling tips, refer to the **"Cooking Made Simple"** booklet.

BROILING CHART

Type of Meat		Doneness	Lower Comp. Broiling*	Total Cook Time**
Hamburgers	3/4" thick	Well	Middle	14-18 min.
Beef Steaks	1" thick	Medium	Middle	14-20 min.
		Well	Middle	16-24 min.
Chicken	Pieces	Well	Bottom	LO Broil (450°) 30-45 min.
Fish Fillets	1/2" thick	Flaky	Middle	8-12 min.
Steaks	1" thick	Flaky	Middle	10-15 min.
Ham Precooked Slice	1/2" thick	Warm	Middle	8-12 min.
Pork Chops	1" thick	Well	Middle	18-25 min.

*Upper is the top position; middle is the lower position; bottom is the bottom of the broiler compartment (remove the rack).

**Broiling times are approximate and may vary depending on the meat.

OVEN COOKING, CONT.

OVEN RACKS

CAUTION:

➢ Do not attempt to change the rack position when the oven is hot.

Your oven has two racks. They are designed with a lock-stop edge.

TO REMOVE: Pull rack straight out until it stops at the lock-stop position; lift up on the front of the rack and pull out.



TO REPLACE: Place rack on the rack support in the oven; tilt the front end up slightly; slide rack back until it clears the lock-stop position; lower front and slide back into the oven.

Do not cover an entire rack with aluminum foil or place foil on the oven bottom. Baking results will be affected and damage may occur to the oven bottom.

RACK POSITIONS



RACK 5: (highest position): Used for some two-rack cooking.

RACK 4: Used for most two-rack baking.

RACK 3: Used for most baked goods on a cookie sheet or jelly roll pan, layer cakes, fruit pies, or frozen convenience foods.

RACK 2: Used for roasting small cuts of meat, casseroles, baking loaves of bread, bundt cakes, custard pies or two-rack baking.

RACK 1: Used for roasting large cuts of meat and poultry, frozen pies, dessert souffles, angel food cake, or two-rack baking.

ROASTING POSITION:

Used for roasting taller cuts of meat or turkey. Place both oven racks, one above the other, on the raised sides of the oven bottom.



MULTIPLE RACK COOKING:

Two rack: Use rack positions 2 and 4, or 1 and 4.

NOTE: Never place pans directly on the oven bottom.

HALF RACK

(Select Models)

TO INSTALL IN OVEN:



1. Always install half rack when oven is cool.
2. To install, grasp top center of the half rack. Align the side arm support between the top fourth and fifth oven rack guides. Insert the two tabs on the back frame of the half rack into the slots on the upper left rear of the oven wall.
3. Push firmly on the top surface of the half rack until the tabs slide into the slots and the half rack side arm support rests on the fourth oven rack guide.
4. Check for proper installation by placing your hand on the top surface of the half rack and pressing down firmly.

TO REMOVE FROM THE OVEN:

When the oven is cool, grasp the top center of the half rack and pull upward until the back tabs on the rack slide out of the oven back slots.



NOTES:

- ➢ Do not use cookware that extends beyond edge of rack.
- ➢ For best results, allow two inches between the pan placed on the rack and the oven side wall.
- ➢ When opening the oven door, allow steam and hot air to escape before reaching into the oven to remove food.
- ➢ Use caution when removing items from the half rack to avoid burns.
- ➢ Carefully remove items from the lower rack to avoid disturbing the half rack.
- ➢ "HALFRACK" Accessory Kit is available when not included with range. Call 1-800-688-8408.

CARE & CLEANING

CAUTION:

- Be sure appliance is off and all parts are cool before handling or cleaning. This is to avoid damage and possible burns.
- To prevent staining or discoloration, clean appliance after each use.
- If a part is removed, be sure it is correctly replaced.

BROILER PAN & INSERT

Never cover insert with aluminum foil as this prevents the fat from draining to the pan below.

- Place soapy cloth over insert and pan; let soak to loosen soil.
- Wash in warm soapy water. Use soap filled scouring pad to remove stubborn soil.
- Broiler pan and insert can be cleaned in dishwasher.

BURNER GRATES

- Wash grates with warm, soapy water and a nonabrasive, plastic scrubbing pad or in the dishwasher. For stubborn soils, clean with a soap-filled, nonabrasive pad or sponge and a commercial Cooktop Cleaning Creme. (Part #20000001.)**
- For burned on soils, remove grates, place on newspapers and carefully spray with commercial oven cleaner. (Do not spray surrounding surfaces.) Place in plastic bags for several hours or overnight. Wearing rubber gloves, remove from bags. Wash, rinse, dry and replace on cooktop.

CLOCK AND CONTROL PAD AREA

- Wipe with a damp cloth and dry.
- Glass cleaners may be used if sprayed on a cloth first. ***DO NOT spray directly on control pad and display area.***

CONTROL KNOBS

- Remove knobs in the OFF position by pulling forward.
- Wash, rinse and dry. Do not use abrasive cleaning agents as they may scratch the finish.
- Turn on each burner to be sure the knobs have been correctly replaced.

COOKTOP, BACKGUARD & CONTROL KNOB AREA

Porcelain enamel is glass fused on metal and may crack or chip with misuse. It is acid resistant, not acid proof. All spillovers, especially acidic or sugary spillovers, should be wiped up immediately with a dry cloth.

- When cool, wash with soapy water, rinse and dry.
- Never wipe off a warm or hot surface with a damp cloth. This may cause cracking or chipping.
- Never use oven cleaners, abrasive or caustic cleaning agents on exterior finish of range.

ENAMEL (PAINTED)

SIDE PANEL, BROILER COMPARTMENT, OVEN DOOR & DOOR HANDLES

- When cool, wash with warm soapy water, rinse and dry. Never wipe a warm or hot surface with a damp cloth as this may damage the surface and may cause a steam burn.
- For stubborn soil, use mildly abrasive cleaning agents such as baking soda paste or Bon Ami*. Do not use abrasive cleaners such as steel wool pads or oven cleaners. These products will scratch or permanently damage the surface.

NOTE: *Use dry towel or cloth to wipe up spills, especially acidic or sugary spills. Surface may discolor or dull if soil is not immediately removed. This is especially important for white surfaces.*

GLASS

OVEN WINDOW & DOOR (SELECT MODELS)

- Avoid using excessive amounts of water which may seep under or behind glass causing staining.
- Wash with soap and water. Rinse with clear water and dry. Glass cleaner can be used if sprayed on a cloth first.
- Do not use abrasive materials such as scouring pads, steel wool or powdered cleaners as they will scratch glass.

METAL FINISHES

TRIM PARTS

- Wash with soap and water, a glass cleaner, or mild liquid detergent.
- To prevent scratching or dulling of the finish, do not use mildly abrasive, abrasive, harsh or caustic cleaners such as oven cleaners.

OVEN INTERIOR

- Clean frequently using mild abrasive and a plastic pad.
- Do not use metallic scouring pads because they will scratch the surface.
- When using commercial oven cleaners follow the manufacturer's instructions.
- Wipe up acidic spills (tomato or milk based foods) as soon as possible with soap and water. If the spill is not wiped up, it may discolor the porcelain.

NOTE: *To make cleaning easier, remove the oven door, if desired. (See Maintenance section, page 11.)*

** To order direct, call 1-800-688-8408.

CARE & CLEANING, CONT.

OVEN RACKS

- Clean with soapy water.
- Remove stubborn soil with cleansing powder or soap-filled scouring pad. Rinse and dry.

PLASTIC FINISHES

TRIM & END CAPS

- When cool, clean with soap and water, rinse and dry.
- Use a glass cleaner and a soft cloth.

NOTE: *Never use oven cleaners, abrasive or caustic liquid or powdered cleansers on plastic finishes. These cleaning agents will scratch or mar finish.*

NOTE: *To prevent staining or discoloration, wipe up fat, grease or acid (tomato, lemon, vinegar, milk, fruit juice, marinade) immediately with a dry paper towel.*

SEALED GAS BURNERS

- Allow burner to cool. Wash with soapy water and a plastic scouring pad. For stubborn soils, clean with a soap-filled, nonabrasive pad.
- Clean gas ports, especially the port below the ignitor, with a straight pin or a soft bristle brush.
- Be careful not to get water into burner ports.
- When cleaning, use care to prevent damage to the ignitor. If the ignitor is soiled, wet or damaged, the surface burner will not light.

MAINTENANCE

OVEN DOOR

CAUTION:

- Do not place excessive weight on or stand on an open oven door. This could cause the range to tip over, break the door, or injure the user.
- Do not attempt to open or close door or operate oven until door is properly replaced.
- Never place fingers between hinge and front oven frame. Hinge arms are spring mounted. If accidentally hit, the hinge will slam shut against oven frame and could injure your fingers.

TO REMOVE:



1. When cool, open the oven door to the first stop position (opened about four inches).
2. Grasp door at each side. Do not use the door handle to lift door.
3. Lift up evenly until door clears hinge arms.

TO REPLACE:

1. Grasp door at each side.
2. Align slots in the door with the hinge arms on the range.
3. Slide the door down onto the hinge arms until the door is completely seated on the hinges. Push down on the top corners of the door to completely seat door on hinges. Door should not appear crooked.

NOTE: The oven door on a new range may feel "spongy" when it is closed. This is normal and will decrease with use.

OVEN LIGHT

CAUTION:

- Disconnect power to range before replacing light bulb.
- Use a dry potholder to prevent possible harm to hands when replacing bulb.
- Be sure bulb is cool before touching bulb.
- Do not touch hot bulb with a damp cloth as this may cause the bulb to break.

TO REPLACE OVEN LIGHT BULB:

1. Remove light bulb.
2. Replace with a 40 watt appliance bulb.
3. Reconnect power to range. Reset clock.

OVEN WINDOW

(Select Models)

1. Do not use abrasive cleaning agents such as steel wool scouring pads or powdered cleansers as they may scratch the glass.
2. Do not hit the glass with pots, pans, furniture, toys or other objects.
3. Do not close the door until the oven racks are in place.

Scratching, hitting, jarring or stressing the glass may weaken its structure causing an increased risk of breakage at a later date.

LEVELING LEGS

CAUTION:

➢ Be sure the anti-tip bracket secures one of the rear leveling legs to the floor to prevent the range from accidentally tipping.

The range should be leveled when installed. If the range is not level, turn the plastic leveling legs, located at each corner of the range, until range is level.



ELECTRICAL CONNECTION

Appliances which require electrical power are equipped with a three-prong grounding plug which must be plugged directly into a properly grounded three-hole 120 volt electrical outlet.

Always disconnect power to appliance before servicing.



The three-prong grounding plug offers protection against shock hazards. Do not cut or remove the third grounding prong from the power cord plug.

If an ungrounded, two-hole or other type electrical outlet is encountered, **it is the personal responsibility of the appliance owner to have the outlet replaced with a properly grounded three-hole electrical outlet.**

REMOVAL OF GAS APPLIANCE

Gas appliance connectors used to connect this appliance to the gas supply are not designed for continuous movement. Once installed, DO NOT repeatedly move this gas appliance for cleaning or to relocate. If this appliance has to be moved and/or removed for servicing, follow the procedure described in the installation instructions. For information contact Maytag Customer Service at 1-800-888-9900.

To prevent range from accidently tipping, range must be secured to floor by sliding the rear leveling leg into the anti-tip bracket.

BEFORE YOU CALL FOR SERVICE

CHECK THESE POINTS IF...

PART OR ALL OF APPLIANCE DOES NOT WORK.

- Check to be sure plug is securely inserted into receptacle.
- Check or re-set circuit breaker. Check or replace fuse.
- Check power supply.
- Check if surface and/or oven controls have been properly set. See pages 5 and 7.

SURFACE BURNER FAILS TO LIGHT.

- Check to be sure unit is properly connected to power supply.
- Check for a blown circuit fuse or a tripped main circuit breaker.
- Check to be sure burner ports or ignition ports are not clogged. See page 5.
- Check to be sure ignitor is dry and clicking. Burner will not light if ignitor is damaged, soiled or wet. If ignitor does not click, turn control knob **Off**.

THE FLAME IS UNEVEN.

- Burner ports may be clogged.

SURFACE BURNER FLAME LIFTS OFF PORTS.

- Check to be sure a pan is sitting on the grate above.

BAKING RESULTS DIFFER FROM PREVIOUS OVEN.

- Temperatures often vary between a new oven and an old one. As ovens age, the oven temperature often "drifts" and may become hotter or cooler.

BAKING RESULTS ARE NOT WHAT YOU EXPECTED.

- Check the oven temperature selected. Make sure oven is preheated when recipe or directions recommend preheat.
- Check rack positions. See page 9.
- Use correct pan. Dark pans produce dark browning. Shiny pans produce light browning. See **"Cooking Made Simple"** booklet for more information on bakeware.
- Check the use of foil in the oven. Never use foil to cover an entire oven rack. Place a small piece of foil on the rack below the pan to catch spillovers.
- Check pan placement. Stagger pans when using two racks. Allow 1–2 inches between pans and oven walls.
- Make sure the oven vent has not been blocked. See page 7 for location.
- Check to make sure range is level.

FOOD NOT BROILING PROPERLY.

- Check oven setting. See page 8.
- Check rack positions. See page 9.
- Aluminum foil was incorrectly used. Never line the broiler pan insert with foil.

OVEN SMOKES EXCESSIVELY DURING BROILING.

- Food too close to flame. See page 8 for more information.
- Broiler insert covered with aluminum foil.
- Excess fat not trimmed from meat prior to broiling.
- A soiled broiler pan was used.

MOISTURE CONDENSATION COLLECTS ON OVEN WINDOW.

- This is normal when cooking food high in moisture.
- Excessive moisture was used when cleaning the window.

STRONG ODOR OR LIGHT SMOKE OCCURS WHEN OVEN IS TURNED ON.

- This is normal for a new range and will disappear after a few uses. Opening a window or turning on a fan will help remove the smoke and odor.
- Excessive food soils on the oven bottom.

NOTES

MAYTAG RANGE WARRANTY

Full One Year Warranty - Parts and Labor

For **one (1) year** from the original retail purchase date, any part which fails in normal home use will be repaired or replaced free of charge.

Limited Warranties - Parts Only

Second Year - After the first year from the original purchase date, parts which fail in normal home use will be repaired or replaced free of charge for the part itself, with the owner paying all other costs, including labor, mileage and transportation.

Third Through Fifth Year - From the original purchase date, parts listed below which fail in normal home use will be repaired or replaced free of charge for the part itself, with the owner paying all other costs, including labor, mileage and transportation.

➢ **Electronic Controls**

Third Through Tenth Year - From the original purchase date, parts listed below which fail in normal home use will be repaired or replaced free of charge for the part itself, with the owner paying all other costs, including labor, mileage and transportation.

➢ **Sealed Gas Burners**

Canadian Residents

The above warranties only cover an appliance installed in Canada that has been certified or listed by appropriate test agencies for compliance to a National Standard of Canada unless the appliance was brought into Canada due to transfer of residence from the United States to Canada.

Limited Warranty Outside the United States and Canada - Parts Only

For two (2) years from the date of original retail purchase, any part which fails in normal home use will be repaired or replaced free of charge for the part itself, with the owner paying all other costs, including labor, mileage and transportation.

*The specific warranties expressed above are the **ONLY** warranties provided by the manufacturer. These warranties give you specific legal rights, and you may also have other rights which vary from state to state.*

WHAT IS NOT COVERED BY THESE WARRANTIES:

1. Conditions and damages resulting from any of the following:
   a. Improper installation, delivery, or maintenance.
   b. Any repair, modification, alteration, or adjustment not authorized by the manufacturer or an authorized servicer.
   c. Misuse, abuse, accidents, or unreasonable use.
   d. Incorrect electric current, voltage, or supply.
   e. Improper setting of any control.
2. Warranties are void if the original serial numbers have been removed, altered, or cannot be readily determined.
3. Light bulbs.
4. Products purchased for commercial or industrial use.
5. The cost of service or service call to:
   a. Correct installation errors.
   b. Instruct the user on the proper use of the product.
   c. Transport the appliance to the servicer.
6. Consequential or incidental damages sustained by any person as a result of any breach of these warranties. Some states do not allow the exclusion or limitation of consequential or incidental damages, so the above exclusion may not apply.

IF YOU NEED SERVICE

- Call the dealer from whom your appliance was purchased or call Maytag Appliances Sales Company, Maytag Customer Assistance at 1-800-688-9900, USA to locate an authorized servicer.
- Be sure to retain proof of purchase to verify warranty status. Refer to WARRANTY for further information on owner's responsibilities for warranty service.
- If the dealer or service company cannot resolve the problem, write to Maytag Appliances Sales Company, Attn: CAIR® Center, P.O. Box 2370, Cleveland, TN 37320-2370, or call **1-800-688-9900 U.S.A. or 1-800-688-2002 Canada.**

  U.S. customers using TTY for deaf, hearing impaired or speech impaired, call 1-800-688-2080.

  NOTE: When writing or calling about a service problem, please include the following information:

  a. Your name, address and telephone number;
  b. Model number and serial number;
  c. Name and address of your dealer or servicer;
  d. A clear description of the problem you are having;
  e. Proof of purchase (sales receipt).
- User's guides, service manuals and parts information are available from Maytag Appliances Sales Company, Maytag Customer Assistance.